

## SI Reset Instructions: BMW 1982-2001 with 20 pin connector

- Plug the device into the 20 pin diagnostic socket of the car located in the engine compartment
- Turn the ignition key to enable the board electronics but do not turn on the motor
- Press the button for the operation you want to perform and keep it pressed
- The LED of the chosen operation will be on
- Keep the button pressed
- Reset is done when the LED is turning off itself
- Release button

Please note on some instrument panels it may be necessary to make an inspection reset before an oil reset.