

SI Reset Instructions: BMW with OBDII Diagnostic Connector

- Plug the device into the OBD2 socket of the car
- All LED's will blink and then stay on
- Turn the ignition key to enable the onboard electronics but do not turn on the engine
- Press the button for the operation you want to perform
- The LED of the chosen operation will light and the other LED's will be off
- LED's will perform a light chain which means reset is done
- On some instrument panels it may be necessary to do an inspection reset before an oil reset.